

# 3M™ Scotchkote™ Urethane Pipe Repair PR 504

## Data Sheet and Application Guide

### Product Description

Scotchkote Urethane Pipe Repair PR 504 is a special fast curing moisture activated repair bandage for repairs to leaking pipes.

### Product Features

Easy to apply, requiring no special tools or equipment.

Specially selected woven polyester fabric impregnated with a polyurethane resin which is activated by immersion in water.

- Ideal for repairing pipes operating at low pressures.
- Designed for use for repairs to pipes upto 65mm diameter.
- Can be used on a wide variety of surfaces, including all metals and many types of plastic.

### General Application Steps

1. Remove oil, grease and loosely adhering deposits.
2. Abrade by appropriate means to create a coarse profile.
3. Apply Scotchkote Urethane Pipe Repair PR 504 to the required thickness.
4. Allow to cure.

### Properties

Property	Value
Colour	Cream
Ratio	N/A, supplied ready for use
<b>Drying &amp; Cure times at 20°C (68°F)</b>	
Useable life	2-3 mins
Initial Set	5 mins
Full Mechanical Cure	30 mins
Volume Solids	100%
<b>Performance Data</b>	
Flexural Strength	32Mpa (4640 psi) (ASTM D790)
Tensile Strength	19 Mpa (2740psi) (ASTM D6382)
Maximum Heat Resistance	270°C (500°F)
Maximum Service Pressure	10 bar (150 psi) - ½ inch/12mm thick repair 27.5 bar (400 psi) – 1inch/25mm thick repair
Shore D Hardness	82 (ASTM D2240)
Adhesion (Bond Strength)	14Mpa (2000 psi)



# Application Procedures for 3M™ Scotchkote™ Urethane Pipe Repair PR 504

All pressure should be removed from the pipe. For leaks where pressure cannot be removed, holes should be stopped using a pipe repair clamp. Remove all oil, grease, loose rust scale, sealant tape and paint from the repair area. Rough score a 10 cm (4 inch) patch around the pipe centring on the leak site.

If the pipe is pitted with rust, surfaces must be wire brushed to remove the loose scale. If the surface is smooth, as with copper or stainless steel, surfaces should be roughened with a coarse file, rasp or saw blade. For plastic pipe, the external mould release must be removed. Abrade surfaces with a coarse grit sandpaper. A saw blade may also be used to create a cross hatch pattern. This is particularly useful on polypropylene and PVDF piping.

## Application Procedures

Before and during application, lightweight disposable gloves should be worn to protect the hands.

Scotchkote Urethane Pipe Repair PR 504 is a single component material, which should be immersed in water and squeezed two or three times for about five seconds prior to use.

Remove roll from water and wrap quickly and tightly as follows.

Centre tape over leak site, wrap from bottom of roll, pulling firmly throughout application. After 5-7 plies, resin foam will come through the tape, which is desirable and aided by pulling tightly. Continue until entire roll is applied, building to a minimum thickness of ½ inch (12 mm), use a second roll if necessary. Firmly press and smooth end of roll into wrap in the direction of application. Wet gloves in water, smooth and firmly press the wet resin back into the wrap.

## Handling and Safety Precautions

Read all health hazard, precautionary and first aid statements found in the Material Safety Data Sheet, and/or product label prior to handling or use.

3M and Scotchkote are trademarks of 3M Company.

## Important Notice

All statements, technical information and recommendations are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using the 3M™ Scotchkote™ Product, you must evaluate it and determine if it is suitable for your intended application. Because conditions of product use are outside of 3M control's and vary widely you assume all risks and liability associated with such use. Any product related statements not contained in current 3M publications, or any contrary statements contained in your purchase order, shall have no force or effect unless expressly agreed to in writing by an authorised officer of 3M.

## Warranty; Limited Remedy; Limited Liability.

3M warrants that the 3M™ Scotchkote™ Product will conform to 3M published specifications upon shipment. If the product is proven not to have met the specifications your exclusive remedy within 12 months of sale by 3M of the product and 3M's sole obligation will be, at 3M's option, to replace the Product or to refund the purchase price of the Product. Except where prohibited by law, this warranty is made in lieu of all other warranties, express or implied, including, but not limited to, any implied warranty of suitability or fitness for a particular purpose, or those arising from a course of dealing, custom or usage or trade.

3M has no obligation under this warranty with respect to any product that has failed due to inadequate or improper storage, handling, surface preparation, application, or maintenance; failure to follow product instructions or recommendations or alteration or damage to the Product caused by accident, neglect, or misuse. OTHER THAN IN THE CASE OF DEATH OR PERSONAL INJURY CAUSED BY ITS NEGLIGENCE AND EXCEPT WHERE PROHIBITED BY LAW, IN NO EVENT SHALL 3M BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL LOSS OR DAMAGES (INCLUDING LOST PROFITS) ARISING FROM THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ASSERTED.



### Infrastructure Protection Division (IsPD) 3M United Kingdom plc

23 Standard Way Industrial Estate  
Northallerton  
North Yorkshire DL6 2XA  
United Kingdom  
Phone: +44 (0)1609 780170  
Fax: +44 (0)1609 780438  
www.3M.co.uk/scotchkote

### Infrastructure Protection Division (IsPD) 3M United Kingdom plc

3M Centre  
Cain Road, Bracknell  
Berkshire RG12 8HT  
Phone: 01344 858000  
Fax: 01344 857970  
www.3M.co.uk

When used in conjunction with a plug of 3M™ Scotchkote™ Epoxy Metal Repair SG 527 repeat the above instructions but having first plugged the hole. Knead a small bead of putty in a gloved hand and flatten out into a disc centrally over the hole pressing gently and feathering out the edges. Leave to semi-harden (full cure 30 minutes) before applying the tape, although the tape may be applied immediately if necessary.

KEEP HANDS MOVING QUICKLY AND WET GLOVES FREQUENTLY TO AVOID STICKING.

Continue rapid hand movement pressing and polishing resin in motions around and parallel to the pipe. Continue process until resins are no longer tacky. The repair should now have a smooth, hard surface and an enamel-like appearance with no fabric protruding through the surface.

NOTE: If a thicker application is needed, spend a little less time finishing the first roll and immediately begin the application of the next. Finish the final roll as if a single roll application.

## Packaging and Storage

Supplied as a rolled bandage in an air tight sachet. Bandage dimension approximately  
10 x 1.5 metre x 50mm.  
5 x 3.6 metre x 50mm  
5 x 3.6 metre x 75mm  
5 x 3.6 metre x 100mm

Use within 12 months of date of manufacture. Store in original sealed containers at temperatures between 5°C and 32°C.

## Ordering Information/Customer Service

For ordering, technical and product information or to request a copy of the Material Safety Data Sheet, call +44 (0)1609 780170 or fax +44 (0)1609 783762 (Sales) or 788718 (Technical).

For emergencies, please contact +44 (0)1344 858000.

Please recycle. Printed in UK.  
© 3M 2013. All rights reserved.  
PR504-0413